



- Spring-loaded two-sided design for use when assembling or removing master links.

Instructions of Use:

- To assemble



- To remove



Note :

- For the proper maintenance of your tools, please apply a rust preventive oil regularly.
- All tools should be stored in a dry environment.