


Depending on the model, Birzman pumps are equipped with either a straight or L-shaped Snap-It Apogee valve head. The same usage instructions are applicable to both options.


Note :

- Please ensure the valve head is parallel with the valve and pressed all the way down when inserted.




- Please refrain from lubrication attempts.

Snap-It Apogee is compatible with:



Replacement Instructions:



Spare O-rings

The grooved side should be facing inwards.

Patented Technology

United Kingdom 2497163	Germany 102014106141	United States US 9249914 B2	Taiwan I498479 I489047	China 1682615
----------------------------------	--------------------------------	---------------------------------------	-------------------------------------	-------------------------